


Menu Structure



Sensor

1. FLAT - smooth plane
2. PIN - rough surface
3. CORE - cylinder of a set diameter

Using GPS

Bluetooth can be used for acquiring GPS data. Before using PC or GPS for the first time, the device must be bounded (paired) with the KM-7, see the manual for details.

The third item of the Setup menu enables/disables Bluetooth connection. If enabled, the forth line BT MENU is displayed where connection to GPS can be established and coordinates displayed - item GPS DATA. BT is disabled if USB cable is connected to the KM-7.

KMdata communication program

KMdata transfers data from KM-7 to PC via USB cable or Bluetooth connection.

In the Scan remote mode, KMdata allows direct acquisition of measurements from the KM-7.

Installation of the program and components is automatic. To install USB drivers, your Windows account must have administration privileges and the KM-7 must be connected via USB cable.

To be able to connect via Bluetooth, the KM-7 must be first bounded to PC (paired), see the manual.

Then the Bluetooth connection of the KM-7 kappameter to a PC in the program KMdata is established automatically when using Windows Vista, Windows 7 and higher (Microsoft Bluetooth stack). This feature is available for almost all Bluetooth adaptors. In the Windows XP, only few Bluetooth adaptors are supported, and the connection must be established manually every time.

SatisGeo, s.r.o.

Postal Address:

Ječná 29a
621 00 Brno
Czech Republic


phone/fax:

+420 541 634 414
info@satisgeo.com
www.satisgeo.com



KAPPAMETER KM-7
Pocket Magnetic Susceptibility Meter

Menu Structure



Sensor

1. FLAT - smooth plane
2. PIN - rough surface
3. CORE - cylinder of a set diameter

Using GPS

Bluetooth can be used for acquiring GPS data. Before using PC or GPS for the first time, the device must be bounded (paired) with the KM-7, see the manual for details.

The third item of the Setup menu enables/disables Bluetooth connection. If enabled, the forth line BT MENU is displayed where connection to GPS can be established and coordinates displayed - item GPS DATA. BT is disabled if USB cable is connected to the KM-7.

KMdata communication program

KMdata transfers data from KM-7 to PC via USB cable or Bluetooth connection.

In the Scan remote mode, KMdata allows direct acquisition of measurements from the KM-7.

Installation of the program and components is automatic. To install USB drivers, your Windows account must have administration privileges and the KM-7 must be connected via USB cable.

To be able to connect via Bluetooth, the KM-7 must be first bounded to PC (paired), see the manual.

Then the Bluetooth connection of the KM-7 kappameter to a PC in the program KMdata is established automatically when using Windows Vista, Windows 7 and higher (Microsoft Bluetooth stack). This feature is available for almost all Bluetooth adaptors. In the Windows XP, only few Bluetooth adaptors are supported, and the connection must be established manually every time.

SatisGeo, s.r.o.

Postal Address:

Ječná 29a
621 00 Brno
Czech Republic

phone/fax:

+420 541 634 414
info@satisgeo.com
www.satisgeo.com



KAPPAMETER KM-7
Pocket Magnetic Susceptibility Meter

Kappameter KM-7

KM-7 is designed for quick field measurements of magnetic susceptibility of outcropping rocks, drill cores and larger pieces of rocks.

Power Supply

Batteries or accumulators AAA, 2 pcs

Turning On/Off

To turn the KM-7 on, press **Enter**.

To turn the KM-7 off, press **Escape** for 3 seconds. The instrument is automatically turned off after cca 40 seconds of inactivity. If the KM-7 is connected to a PC via USB/Bluetooth, or connection to Bluetooth GPS is active, the automatic turn off is disabled.







Buttons

Enter - going to a sub menu, enabling editable items, activating action items, storing a value to the memory

Escape - terminating an action on editable items without change, returning to an upper menu

Up, Down - browsing among menu items, selecting values from predefined editable items
The position of the arrow at the left side of the display points to the selected menu item.

Icons

	Battery status icon
	KM-7 conn. to PC via USB cable
	Bluetooth enabled
	KM-7 conn. to PC via Bluetooth
	GPS data valid
	Measuring in progress

Kappameter KM-7

KM-7 is designed for quick field measurements of magnetic susceptibility of outcropping rocks, drill cores and larger pieces of rocks.

Power Supply

Batteries or accumulators AAA, 2 pcs

Turning On/Off

To turn the KM-7 on, press **Enter**.

To turn the KM-7 off, press **Escape** for 3 seconds. The instrument is automatically turned off after cca 40 seconds of inactivity. If the KM-7 is connected to a PC via USB/Bluetooth, or connection to Bluetooth GPS is active, the automatic turn off is disabled.







Buttons

Enter - going to a sub menu, enabling editable items, activating action items, storing a value to the memory

Escape - terminating an action on editable items without change, returning to an upper menu

Up, Down - browsing among menu items, selecting values from predefined editable items
The position of the arrow at the left side of the display points to the selected menu item.

Icons

	Battery status icon
	KM-7 conn. to PC via USB cable
	Bluetooth enabled
	KM-7 conn. to PC via Bluetooth
	GPS data valid
	Measuring in progress

Modes

1. **Single** - one measurement.
2. **Scan** - data are continually measured, results are displayed on the display only.
3. **Scan remote** - continual measurement, the measured data are transferred to the PC via USB or Bluetooth and processed by the program KMdata.

Measuring in Single mode

- Set sensor (Flat, Pin, Core) in Setup menu. Be sure the pin is properly screwed to the head when setting PIN.
- When measuring with GPS, make sure the USB cable is disconnected, set BT ON in Setup menu, set BT GPS in BT MENU, turn on the GPS and wait for connection. When measuring without GPS, set BT OFF in Setup menu.
- Select Measure in main menu, set Single mode. Measuring is done in three steps, with maximum 10 s between them.
 1. initial measurement with the instrument placed minimum 30 cm far from the sample (AIR1), press Enter
 2. measurement of susceptibility with the black head of the instrument placed parallel to the surface of the sample (SAMPLE), press Enter
 3. final measurement with the instrument placed minimum 30 cm far from the sample (AIR2), press Enter
- Do not move instrument while the icon M is displayed (collecting signal ca 0.5 s).
- Save the displayed value by Enter, delete it by Escape.
- Repeat the three steps or finish by Escape.

Modes

1. **Single** - one measurement.
2. **Scan** - data are continually measured, results are displayed on the display only.
3. **Scan remote** - continual measurement, the measured data are transferred to the PC via USB or Bluetooth and processed by the program KMdata.

Measuring in Single mode

- Set sensor (Flat, Pin, Core) in Setup menu. Be sure the pin is properly screwed to the head when setting PIN.
- When measuring with GPS, make sure the USB cable is disconnected, set BT ON in Setup menu, set BT GPS in BT MENU, turn on the GPS and wait for connection. When measuring without GPS, set BT OFF in Setup menu.
- Select Measure in main menu, set Single mode. Measuring is done in three steps, with maximum 10 s between them.
 1. initial measurement with the instrument placed minimum 30 cm far from the sample (AIR1), press Enter
 2. measurement of susceptibility with the black head of the instrument placed parallel to the surface of the sample (SAMPLE), press Enter
 3. final measurement with the instrument placed minimum 30 cm far from the sample (AIR2), press Enter
- Do not move instrument while the icon M is displayed (collecting signal ca 0.5 s).
- Save the displayed value by Enter, delete it by Escape.
- Repeat the three steps or finish by Escape.

Measuring in Scan mode

- Set sensor (Flat, Pin, Core) in Setup menu.
- Select Measure in main menu, set Scan mode.
- Make initial measurement with the instrument placed minimum 30 cm far from the sample (AIR1), press Enter.
- Place the black head of the instrument parallel to the surface of the sample (SAMPLE), press Enter.
- Measuring at the sample is repeated until Escape.

Measuring in Scan remote mode

- Set sensor (Flat, Pin, Core) in Setup menu.
- When using Bluetooth, set BT ON in Setup menu and BT PC in BT MENU, otherwise connect USB cable.
- Run program KMdata on PC, connect to the KM-7, go to Scan remote tab of the KMdata. Wait for the connection – check the icon.
- Select Measure in main menu, set Scan remote mode.
- Make initial measurement with the instrument placed minimum 30 cm far from the sample (AIR1), press Enter.
- Place the black head of the instrument parallel to the surface of the sample (SAMPLE), press Enter.
- Measuring at the sample is repeated until Escape.

Measuring in Scan mode

- Set sensor (Flat, Pin, Core) in Setup menu.
- Select Measure in main menu, set Scan mode.
- Make initial measurement with the instrument placed minimum 30 cm far from the sample (AIR1), press Enter.
- Place the black head of the instrument parallel to the surface of the sample (SAMPLE), press Enter.
- Measuring at the sample is repeated until Escape.

Measuring in Scan remote mode

- Set sensor (Flat, Pin, Core) in Setup menu.
- When using Bluetooth, set BT ON in Setup menu and BT PC in BT MENU, otherwise connect USB cable.
- Run program KMdata on PC, connect to the KM-7, go to Scan remote tab of the KMdata. Wait for the connection – check the icon.
- Select Measure in main menu, set Scan remote mode.
- Make initial measurement with the instrument placed minimum 30 cm far from the sample (AIR1), press Enter.
- Place the black head of the instrument parallel to the surface of the sample (SAMPLE), press Enter.
- Measuring at the sample is repeated until Escape.